

#### - Wash the roller with water, and remove any dirt from the surface of the cleaning roller with your finger. Allow the cleaning roller to air dry. 4

- Set the cleaning unit, and close the printer door. 5.
- computer to unlock the printer. After closing the door, turn on the function again from the computer.
- · Start work after ensuring that the power has been turned off.
- · If the printer is used every day, make sure to clean the cleaning roller daily at the end of the operation.
- · After washing, allow the cleaning roller to dry completely before installing it to the printer.
- Do not wash the cleaning roller with anything other than water (e.g., alcohol). • Replace the cleaning unit with a new one after using it for about one year.
- For details on its replacement, please consult our authorized dealers.

# **Quick Start Guide**

# EDISecure® **XID8300** Retransfer card printer

#### Thank you for purchasing this product.

Please read through the User Manual located at www.maticagroup/install/XID8300 in advance to ensure proper use of this product. To make sure that this product is used safely, please read through the "Safety Precautions" in the "READ ME FIRST" booklet.

## Document contents and informat

#### Accessories

<ul> <li>Quick Start Guide</li> </ul>	x1	
<ul> <li>READ ME FIRST (LST1013)</li> </ul>	x1	
<ul> <li>Power cord (2 m)</li> </ul>	x1	
<ul> <li>Cleaning card</li> </ul>	x1	
<ul> <li>Card stacker</li> </ul>	x1	
<ul> <li>USB 2.0 cable (2m)</li> </ul>	x1	
Gloves	x1	
Tweezers	x1	

Tweezers

#### Products sold separately

To purchase these items, consult our authorized dealers. Use the retransfer film or ink ribbon within half a year after purchase.

#### Ribbon

#### Capacity Part N 1,000 prints DIC10

1,000 prints

- ChromXpert platinum line ink ribbon (YMCK) 750 prints
- ChromXpert platinum line ink ribbon (YMCKK)
- ChromXpert platinum line ink ribbon (YMCK-PO) 750 prints 750 prints
- ChromXpert platinum line ink ribbon (YMCK-UV)
- ChromXpert platinum line retransfer film
- Cleaning kit, set includes:
- 10 printhead cleaning swabs,
- 10 cleaning tissues for rollers
- 10 special cleaning cards
- Magnetic stripe encoder head cleaning cards

#### **Content of Instruction Manual**

Before use :	Precautions, disclaimer, etc.
Operating the printer :	Procedures for printing cards
Replacement :	Procedures for replacing consumable items
Maintenance :	Cleaning procedures
Troubleshooting :	Actions to take when troubles occur

- Troubleshooting Setup :
  - Installation, connection

#### Specifications

- Operating environment conditions :
- Temperature: 15 °C to 30 °C
- (When peel-off ink, UV ink is used: 17 °C to 28 °C)
- Humidity: 35 % to 70 % No condensation
- (When peel-off ink, UV ink is used: 35 % to 60 %)
- Storage environment conditions :
- <Printer unit>
- Temperature : -15 °C to 55 °C Humidity : 20 % to 80 %
- <Printing media (retransfer film or ink ribbon) / card>
- Temperature : 5 °C to 25 °C
- Humidity : 40 % to 60 %
- Power supply : AC 100 V 120 V, 50 Hz/60 Hz, AC 220 V 240 V, 50 Hz/60 Hz
- Power consumption : 310 W (maximum power when all options are installed)
- Current consumption : 3.5 A (100 V system), 1.6 A (200 V system)
- Mass approx. : 14.4 kg (single-sided printer, excluding optional built-in items)
- Dimensions : 343 x 411x 322 mm (W x H x D)

NB. The specifications and appearance of this product may be modified for improvement without prior notice.


### maticagroup.com


Copyright 2023 Matica Technologies Group SA. All rights reserved. Information in this document is subject to change without prior notice.



mation	Function and checklist	Function and option checklist		
		Use the checklist below to identify the functions and options of the printer in use.		
e. <b>Part Number</b> DIC10216 DIC10217 DIC10218 DIC10313 DIC10319 DIK10044	Model name:			
	Function	Tick accordingly		
	Single-sided printing :	$\bigcirc$		
	Double-sided printing :	$\bigcirc$		
	Option	Tick accordingly		
	Bend remedy unit :	$\bigcirc$		
	Magnetic stripe encoder :	$\bigcirc$		
	Contact IC :	$\bigcirc$		
DIC10311	Encoder :	$\bigcirc$		
	Non-contact IC :	$\bigcirc$		
	Encoder :	$\bigcirc$		
ems				

XID8300	





- shafts, and insert it firmly into the bobbin holders.
- 4. Remove any slack in the retransfer film/ink ribbon, and insert the cassette along the guide rail until a "click" sound is heard.
- 5. Close the printer door, and press Reset → ← to reset the printer.

### Precautions

- If the security lock function is turned on, turn off the function from the computer to unlock the printer. After closing the door, turn on the function again from the computer.
- · When installing a used ink ribbon, align the yellow side of the unused ribbon with the arrow indicated on the label of the cassette.
- · When installing a used retransfer film, align the unused side of the film with the arrow indicated on the label of the cassette.
- · Stand the cassette on a flat surface as illustrated in the diagram.
- The cassette is heavy when the retransfer film/ink ribbon is loaded. To prevent the cassette from dropping during handling, make sure to hold it with both hands.
- Do not touch the retransfer/inked face (the side that faces outward when installed) with your hand. Touching it may cause printing errors.
- Put on the supplied gloves when handling the retransfer film/ink ribbon. · Do not perform any work on the printer
- door. Do not place heavy objects or apply load on the printer.
- When installing a new film, make sure that at least three black lines are wound onto the take-up side.


# Install printer driver

#### Visit: www.maticagroup.com/install

Or scan the QR code opposite using your computer's webcam to the installation page and follow the online instructions.


#### Download and install driver

· Follow the online step-by-step guide to download and install the printer driver.



- Turn on the power. 1.
- 2. Check to ensure that cards are inserted into the card hopper.
- Open the software's print settings screen, 3. and select this printer in [Name].
- After ensuring that a [Ready] message 4 appears on the LCD panel of the printer, start printing.







XID8300



### 3 4 Ready Total \* \* \* Menu Reset + $\square$ $\square$

#### Precautions

- If you see an [Initializing..] or [Preheating..] message on the LCD panel of the printer, this means the printer is not ready yet. Printing cannot be performed until a [Ready] massage appears.
- Printing the card on the side with the magnetic stripe may cause printing errors or damage to the card's functions. If you want to do so, please consult our authorized dealers in advance.
- For printing using application software prepared by the user, refer to the instruction manual of the corresponding software.

- When using new cards, set them after making sure that they are not adhered to each other due to static.
- Align the cards before setting them in the printer. Otherwise, the card hopper cover may not close properly, and this may damage the printer.